



KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
1	H40061	Cutlery Bin, 4-Compartment, Gray	11	H70062	Fry Carton Dispenser, Regular
2	H80019	French Fry Scale	12	H10114	Salt Shaker Dredge w/Handle, S/S
3	H50119	Timer, 24-hr w/Memory	13	H10131	Salt Dredge w/Handle, Clear Plastic
4	H80044	Timer, Digital, 4 Cycle, Gray	n/s	H10115	Portion Control Dredge, Accu-Salt
5	QTDIVSBS	Half Moon Divider, 3-Tab	14	H70060	Coin Changer, Standard
6	H10079	Order Holder, 30"	15	H70061	Coin Changer w/Bumper
7	H10048	Tong, 9", Yellow, S/S	16	H40116	Carhop Tray, Red
8	H10047	Tong, 9", Red, S/S	17	H70085	French Fry Channel, 38"
9	H10191	Fry Scoop, Right Handle	18	H70074	French Fry Channel, 15-1/2"
10	H10127	Fry Scoop, Nylon, RH			