



KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
A	SR82060	Complete Unit w/Pump, 120V	19	SR82018	Head Insert
B	SR82120	Pump Assembly, w/Lid, FP-V, Rectangular	20	SR82077	Spring, 3/8"Dx7"L
1	SR81320	Pump Assembly, w/Lid, FSP, Round	21	SR82015	Washer
2	SR82063	Spacer, 3-Spoke	22	SR82076	Piston & Stem Assembly, FP-V
3	*	Water Vessel Replacement Kit, 120V <i>* consult factory for part number</i>		SR82013	Piston & Stem Assembly, FSP
4	SR81051	Element Bank, 120V, 500W	23	SR82027	Discharge Tube Nut
5	SR55034	Thermostat Kit	24	SR82487	Discharge Tube Assembly, FP-V
6	SR82066	Base only for Fudge Server		SR82485	Discharge Tube Assembly, FSP
7	SR04544	Switch Rocker	25	SR05127	O-Ring, 1"
8	SR81157	Knob Guard	26	SR06022	Ball, Stainless Steel, 2 ct.
9	SR11217	Cord Assembly	27	SR82334	Valve Body
10	SR11201	Strain Relief Bushing	28	SR82323	O-Ring
11	SR81037	Thermal Cutout	29	SR82348	Cylinder Assembly, FP-V
12	SR81055	Knob, Thermostat		SR82336	Cylinder Assembly, FSP
13	SR81058	Foot w/Screw	30	SR82071	Lid, FP-V
n/s	SR94009	Stainless Steel Jar		SR82061	Lid, FSP
14	SR82023	Knob, Black	31	SR83003	Seal Assembly
15	SR82035	"O" Ring Knob	32	SR82526	Brush, 21"
16	SR82021	Locking Collar	33	SR82049	Brush, 1-1/4" Diam.
17	SR82022	Gauging Collar, 4 ct.	34	SR40179	Lubricant
18	SR82078	Head Tube, FP-V	35	SR94009	Jar Insert, 3qt, S/S
	SR82017	Head Tube, FSP	n/s	SR82423	Parts Kit