



| KEY | PART # | DESCRIPTION | KEY | PART # | DESCRIPTION |
|-----|-------------|--|-----|------------|---------------------------|
| 1 | RDRD100-01 | Griddle Plate Assembly (specify Model #) | 21 | RDRD100-21 | Flame Switch |
| 2 | RDRD100-02 | Burner, Infra-Red | 22 | RDRD100-22 | Spark Module, SM2 |
| 3 | RDRD100-03 | Pilot Assembly | 23 | RDRD100-23 | Grease Drawer |
| n/s | RDRD100-04 | Orifice, Natural | 24 | RDRD100-24 | Burner Spacer, Right Side |
| | RDRD100-04A | Orifice, L. P. | | | |
| 5 | RDRD100-05 | Solenoid Valve | | | |
| 6 | RDRD100-06 | Toggle Switch | | | |
| 7 | RDRD100-07 | Sensor Probe | | | |
| 8 | RDRD100-08 | Thermostat, Solid State | | | |
| 9 | RDRD100-09 | On/Off Indicator Light, Green | | | |
| | RDRD100-09A | Burner Ignition Light, Red | | | |
| 10 | RDRD100-10 | Burner Spacer, Center | | | |
| 11 | RDRD100-11 | Knob | | | |
| 12 | RDRD100-12 | Burner Spacer, Left Side | | | |
| 13 | RDRD100-13 | Front Panel, (specify Model #) | | | |
| 14 | RDRD100-14 | Back Panel, (specify Model #) | | | |
| 15 | RDRD100-15 | Power Cord | | | |
| 16 | RDRD100-16 | Unit Body, (specify Model #) | | | |
| 17 | RDRD100-17 | Adjustable Leg | | | |
| 18 | RDRD100-18 | Gas Regulator, Natural | | | |
| | RDRD100-18A | Gas Regulator, L. P. | | | |
| 19 | RDRD100-19 | Shutoff Valve, Gas Service | | | |
| n/s | RDRD100-20 | Manifold, (specify Model #) | | | |