

# 1400 SERIES ELECTRIC DECK OVEN REPLACEMENT PARTS LIST

# **EFFECTIVE DECEMBER 6, 2017**

Superseding All Previous Parts Lists.

The Company reserves the right to make substitution in the event that items specified are not available.

ERRORS: Descriptive and/or typographic errors are subject to correction.

#### **BLODGETT OVEN COMPANY**

IMPORTANT: When ordering parts, please provide the model, gas type and serial number of the oven. The identification plate is located on the left side of the combustion compartment and, also, above the control panel under the ledge.

# ✓ ASAP Distributor Required Stocking Parts♦ Doors Are Not Returnable

#### **ELECTRICAL COMPONENTS**

Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
1	53666	Element Assy., Bottom 208V, 3 ph
1	53668	Element Assy., Bottom 240V, 3 ph
	53667	Element Assy., Top 208V, 3 ph
	53669	Element Assy., Top 240V, 3 ph
	53580	Element Assy., Middle 208V, after 4/27/10
	53581	Element Assy., Middle 240V, after 4/27/10
	53582	Element Kit, Middle upgrade to
		non-removeable 208V, 3 phase
	53583	Element Kit, Middle upgrade to
		non-removeable 240V, 3 phase
	53660	Element Kit, Bottom, 208V, 1 phase
	53661	Element Kit, Top, 208V, 1 phase
	53662	Element Kit, Bottom, 240V, 1 phase
	53663	Element Kit, Top, 240V, 1 phase
	53664	Element Kit, Middle upgrade to
		non-removeable 208V, 1 phase
	53665	Element Kit, Middle upgrade to
		non-removeable 240V, 1 phase


#### INTERIOR COMPONENTS

Ref. <u>No</u> .	Part <u>No.</u>	Description
	19955 31144	Deck, Steel Deck, Cordierite (3/4" x 19-1/2" x 19-1/2")

#### **EXTERIOR COMPONENTS**


Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
	20095 21556 20139 21552 20734 21528 17559 21527 23009 20140 35184	Door Assy., S/S, Drop Down (After 2/10/89) Brackets, Door Arm Roll-Up Bearing, Door Roll-Up (Set of 2) Hinge Pin, Door Roll-Up (Set of 2) Microswitch Assy., Door Roll-Up Bearing, Door Drop-Down (Set of 2) Bushing, Roll-Up Hinge Pin, Door Drop-Down (Set of 2) Handle, Door Conversion Kit (Before 11/15/91) Handle, Door (w/rod), (After 11/15/91) Window Bracket (L & R) (for handles)
	00104	(For units after 11/15/91)
	**NOTE	This Kit 35184 replaces 20533 & 20534 single brackets.
	20527 57628 20535 19556 20557 20536 21109 20435 24934 32298 19806 53530 20431 20524	Catch, Door (Pressure Latch) Catch, Door (Striker Plate) Gasket, Top Door S/S Nameplate, Blodgett 4" Back Panel, Louvered Body Top & Sides, S/S Stacking Kit, 1400 on 1400 Legs, 4" Painted (Set of 4) Stand, 19" S/S w/ Casters Heat Shield (1405/1415) Bodyback (before 4/27/2010) Bodyback (after 4/27/2010) Lower Deck Seal (crumb catcher) Angle, Door Seal (upper)

# **MECHANICAL CONTROLS**




Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
30 ☑	15956	Timer, 60 Minute
	16686	Knob, Timer
31	21554	Buzzer, Timer 240V
28	20546	Thermostat w/ Terminal, Mechanical
22	16686	Knob, Thermostat
27	18353	Terminal Adapter, Thermostat
6	19619	Rocker Switch, DPST, Black
29	20436	Indicator Light, 250V, Clear, Rectangular
	20547	Contactor, 30 Amp., 3 Pole (For Solid State Thermostat)
	17556	Terminal Block, 90 Amp., 3 Pole
	23086	Suppressor Assy., RC
$\overline{\checkmark}$	21430	Axial Fan, 230V, 34 CFM, 3"
24	21553	Cable Assy., Strain Relief


### **SOLID STATE INFINITE CONTROLS**




Ref. <u>No</u> .		Part <u>No.</u>	<u>Description</u>	
50	$\overline{\checkmark}$	18578	Control, Temperature	
	$\checkmark$	18588	Probe, Temperature	
34	$\checkmark$	18234	Potentiometer, Remote	
41		16037	Light, Ind. 250V Red, Round	
48	$\checkmark$	18226	Timer, 60 Minute 240V	
6	$\checkmark$	19619	Switch, Rocker DPST, Black	
		35886	Buzzer, 240V	
		20547	Contactor, 3Pole 30 AMP	
		19751	Clip, Bulb Thermistor	
22		16686	Knob, Control	
47		18268	Nylon Spacer	

# **SOLID STATE DIGITAL CONTROLS**








Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
13	51584	Controller, For ovens manufactured after 4/27/08
8	24181	Knob, Control (2), For ovens manufactured before 4/27/08
$\overline{\checkmark}$	23392	Probe, Temperature RTD
6	19619	Rocker Switch, DPST, Black
4	21553	Cable Assy., Strain Relief
	24193	Wiring Harness, Solid State Control Module
5	32472	Control Panel & Decal Assy. 3 Button (Includes the Controller)
9	31192	Decal Only (For 2 Button)
	51392	Decal Only (For 3 Button)
12	36617	Knob, control (1) For ovens manufactured after 4/27/08
	51700	Kit, upgrade from 2 button to 3 button
10	56760	High Limit Switch, For ovens manufactured after 5/27/13
11	36755	Thermal Switch, Cooking Fan, For ovens manufactured after 5/27/13
	21430	Axial Fan, 230V, 34 CFM, 3"

NOTE: If you do not have a 32472 in stock, you can use the the 24448 conversion kit in its place.

# SOLID STATE DIGITAL CONTROLS 12 Key



Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
	24448	Conversion Kit, 12 Button to Current Control with 3 Button Decal (Complete Module Assy.) (See Note)
22	16686	Knob, Control
36	19735	Probe, Temperature Controller RTD
34 ☑	18234	Potentiometer, Remote
21	19619	Rocker Switch, DPST, Black
29	20436	Indicator Light, 250V, Clear, Rectangular
24	21553	Cable Assy., Strain Relief
	24193	Wiring Harness, Solid State Control Module

NOTE: If you need either the timer or the control panel and decal assy. for the 12 button control, you need to order part number 24448 conversion kit to update to the current control with 3 button decal.