

## COS-20G COMBI OVEN-STEAMER REPLACEMENT PARTS LIST

## **EFFECTIVE OCTOBER 14, 2014**

Superseding All Previous Parts Lists.

The Company reserves the right to make substitution in the event that items specified are not available.

ERRORS: Descriptive and/or typographic errors are subject to correction.

#### **BLODGETT OVEN COMPANY**

#### SERIAL NUMBER LOCATION / KEY:

IMPORTANT: When ordering parts, please provide the model, gas type and serial number of the oven. The identification plate is located on the left side of the combustion compartment and, also, above the control panel under the ledge.

# SERIAL NUMBER IDENTIFICATION CODE: HP & HT COS-20G

#### **SERIAL NUMBER EXAMPLES**

062001HP001
06/20/01 = DATE
HP = LETTER CODE FOR MODEL NAME
001 = FACTORY SEQUENCE
OR
0685HT1820101
06/85 = MONTH & YEAR
HT = LETTER CODE FOR MODEL NAME
1820101 = FACTORY SEQUENCE

#### TO OBTAIN LITERATURE:

Email: literature@blodgett.com or visit www.blodgett.com


## **TABLE OF CONTENTS**

OVEN INTERIOR PARTS	3
ELECTRICAL COMPARTMENT	4
GAS & PLUMBING COMPONENTS	6
CONTROL PANEL DOOR & EXTERIOR COMPONENTS	8

## **OVEN INTERIOR PARTS**

Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
	R4272	Baffle, air
	R8130	Baffle & filter retrofit
	R5081	Blower wheel assy (after 1/96)
	R1028	Blower wheel assy (before 1/96)
	R3760	Filter, grease
	R2112	Seal, capillary tube P5 thermostat

#### **ELECTRICAL COMPARTMENT**




## **ELECTRICAL COMPARTMENT**

Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>	Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
1	R3662	Thermostat, control compartment hi limit F7			
2	R2801	Thermostat, P1		R3953	Burner assy, 4-3/4" (after 10/96)
3	R1573	Thermostat, cooking compartment hi limit F3		R5326	Gasket assy, burner (after 10/96)
4	R6402	Timing board		R3713	Orifice, natural (after 10/96)
5	R5707	Level control board (HT s/n)		R3753	Mounting plate, burner
•	R5777	Conversion kit, level control board		R3464	Gasket, flue outlet/burner plate
6	R1586	Terminal block, supply		R4709	Flame sensor, steam generator
7	R4753	Contactor, motor 120V K1		R4243	Thermocouple, hi limit
8	R6021	Transformer, 120/24V		R4193	Ignitor
9 10	R3983 R7174	Relays, R1 R2 R3 R4, 120V Relay SPST 120V R8 (from 110797HT on)		R3462 R3463	View port, mica
10	R7174 R7175	Clip, relay mounting (from 110797HT on)	23	R3463 R11008	Ring, view port mounting Hose, generator fill 3/8" ID (5' piece)
11	R3983	Relay 120V R7	23	R1006	Clamp, hose generator fill
11	R7515	Upgrade kit, relay (adds Solid State R6 &	24	R6965	Probe assy, level sensing
	117313	R8)	24	R5361	Probe only, level sensing assy (HT s/n)
	R8163	Upgrade kit, relay (Solid State R6 &		R1491	Gasket, probe only
	110100	Hardware)		R3141	Probe, level sensing, short (HP s/n)
	R10490	Relay, R6 only	25	R0118	Thermostat, steam pre-heat priority P3
12	R9497	Buzzer, 120V	26	R2630	Thermostat, steam generator hi limit F6
13	R5925	Ignition control, steam	27	R4891	Overpressure assy, steam
14	R1443	Temperature control board, steam P2	28	R4579	Hose, steam outlet
	R0022	Sensor, steam temperature		R4710	Clamp, hose steam outlet
15	R5108	Motor, 115/230V 1/2hp (after 1/96)	29	R2202	Drain manifold connecting boot
	R9648	Seal,washer 1/4" I.D. (after 1/96)		R2207	Clamp, drain boot
	R4244	Seal, rotary shaft (after 1/96)	30	R3661	Thermostat, quench P4
	R4712	Motor, 120V 60hz (before 1/96)		R3755	Gasket, capillary bulb P4
	R4726	Capacitor, motor (before 1/96)		R5414	Grommet, P4
	R2328	Packing rope w/insulation (before 1/96)	31	R11210	Regulator, water pressure
16	R4511	Motor, combustion blower 1 speed	32	R2467	Boot, rubber drain
		(after 10/96)		R0082	Clamp, boot small
	R4710	Clamp, combustion blower (after 10/96)		R2487	Clamp, boot large
	R4746	Motor, combustion blower 2 speed	33	R3555	Pump, drain 115V
		(before 10/96)		R6870	O'ring, drain pump
	18234	Potentiometer, blower (before 10/96)	34	R11008	Hose, decalcifier inlet 3/8" ID (5' piece)
17	M5495	Solenoid valve, gas 1/2" (after 10/96) steam	35	R2998	Decalcifier inlet, threaded
	R4713	Solenoid valve, gas 3/4"	36	R3654	Handle, drain decalcifier
4.0	D.4740	(before 10/96) steam	37	R5429	Hook, hose hanger
18	R4713	Valve gas, combination 3/4"	39	R0261	Motor protector F2 (before 1/96)
19	20348	Ignition module, hot air	40	R5833	Motor protector F2 (from 1/96 - 10/96)
22	R6380	Steam generator insulated	40	R2506	Relay, time delay M2U (before 10/96)
	R4577	Insulation, steam generator	41	R3984	Relay, ice cube DPST 24V (before 10/96)
	R5327	Gasket assy, burner (before 10/96)	42	R0046 R5956	Holder, fuse
	R3170	Orifice, natural (before 10/96)	43	K0900	Gauge, direct steam

## **GAS AND PLUMBING COMPONENTS**

#### **BOTTOM SECTION**




## **GAS AND PLUMBING COMPONENTS**

#### **BOTTOM SECTION**

Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
1 2	R11210 R1088 R11302 R0254	Regulator, water pressure Hose, boiler drain/venturi 7/8" ID (orange) (per foot) Hose, boiler drain/venturi 7/8" ID (green) (per foot) Clamp, hose venturi
3	R4224	Quench assy
4	R3643	Nozzle assy, quench
5	R3755	Gasket, quench thermostat P4
	R5414	Grommet, quench thermostat P4
6	R2202	Drain manifold connecting boot
	R2207	Clamp, drain boot
_	R2868	Gasket, drain/cavity
7	R11008	Hose, water supply 3/8" ID (5' piece)
•	R0082	Clamp, hose water supply
8	R5095	Solenoid valve, triple 115V
0	R5077	Valve body, solenoid triple
9	R5096	Solenoid valve, single 115V
	R5076 R5074	Valve body, solenoid single Coil, solenoid valve
	R5074 R5071	Fitting, barbed solenoid valve
	R3975	Fitting, compression solenoid valve
	R4423	Gasket, heat exchanger
	R4427	Plate, top
	R2953	Burner assy, hot air
	R3465	Orifice, burner assy hot air natural
	R4551	Pilot assy, hot air natural
	R4628	Orifice, pilot natural
	R5718	Pilot assy, hot air LP
	R4633	Wire, flame sensor hot air
	R7835	Vent kit (HP s/n)

# **CONTROL PANEL, DOOR & EXTERIOR COMPONENTS**



# **CONTROL PANEL, DOOR & EXTERIOR COMPONENTS**

Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>	Ref. <u>No</u> .	Part <u>No.</u>	<u>Description</u>
1	16470	Nameplate, Blodgett 10"	7	R4623	Switch, mode 4 position
2	R5797	Glass, window		R8515	Knob & shaft assy, mode switch
	R2105	Gasket, glass window (per foot)		R5686	Switch, mode 3 position
3	R3460	Door, complete	8	R6407	Temperature controller, hot air 150-500° P5
	R4191	Gasket, door perimeter		33152	Temperature controller, hot air 200-500° P5
	R3496	Retainer strip, gasket (vertical)		16686	Knob, temperature controller
	R3497	Retainer strip, gasket (horizontal)		R6003	Probe, hot air temperature
	R6979	Gasket, door guard	40	16686	Knob, timer
	R0922	Catch, door roller (on oven)	10	R4622	Switch, meat probe 1 position
	R0923	Catch, door roller (on door)	11	R5242	Thermostat, meat probe (after 10/96)
	R4588	Switch assy, door		R6746	Thermostat, meat probe (before 10/96)
	4068	Grommet, door switch		R5315	Probe, meat 500 degree Teflon Cable
	R2844 R4130	Pin, door switch Bracket, hinge top		R5317	(plug-in type)
	R4130 R3510	Pin, hinge botm		R6988	Conversion kit, meat probe (to plug-in type) Suppressor arc, meat probe
	15932	Bushing, door top & bottom	12	R2998	Decalcifier inlet, threaded
4	R0278	Handle assy, door (before s/n 011399)	13	R3654	Handle, drain decalcifier
7	R8162	Handle assy, door (after s/n 011399)	10	R3155	Valve, decalcifier with fittings
	R7888	Bar, door handle		R3011	Black cap, decalcifying
	R1082	Cam, door handle	14	R2715	Switch, momentary Flush/Drain
	R1009	Insert, plastic door cam		R9051	Hose & spray nozzle
	R0274	Catch, door		R7854	Control, Time & Temp
	R6899	Mount, cam door handle	15	R0364	Knob, gas valve manual
	R3052	Shim gasket s/s, door handle		R4435	Gas valve, manual
	R7889	Support, door handle		R5803	Handle, transport cart
	R7867	Washer, brass door handle		R5381	Deflector, drip transport cart
	R1083	Washer, acetal door handle 1.625 ID		R0432	Seal, transport cart (per foot)
	R1080	Washer, spring door handle			
	R1079	Washer, flat door handle			
5	R3557	Light, indicator 120V green			
6	R3556	Light, indicator 120V clear			
	R3558	Light, indicator 28V clear			