

Parts list - Structure

Item	Part N°	Description
1	0D7592	Lid
2	0D7593	Hinge shaft
3	0D7594	Hinge cover
4	0D7595	Cone
5	0D7596	Basket driver
6	0D7597	Hex bar
9	0D7600	Ball bearing
10	0D7601	Shaft
11	0D7602	Power cord
12	0D7603	View tube assembly
13	0D7604	Reservoir
15	0D7606	Drain cap
16	0D7607	GH connector
17	0D7608	Base
18	0D7609	Motor
19	0D7610	Castor wheel
20	0D7611	Bottom plate
21	0D7612	Contacto
22	0D7613	Voltage relay
23	0D7614	7,5uf capacitor
24	0D7615	45uf capacitor
25	0D7616	PCB cover
26	0D7617	PCB
27	0D7618	Timer cover clip
28	0D7619	Timer mounting plate
29	0D7620	Timer knob
30	0D7621	Timer cover
31	0D7622	Timer swith
32	0D7623	Timer hinge cover
33	0D7624	Cylinder
34	0D7625	Command box
35	0D7626	ON swithes
41	0D7707	OFF swithes
36	0D7627	Basket
37	0D7628	Magnet
38	0D7629	Magnet cover
39	0D7630	Oil seal
40	0KQ433	Rubber protection
S1	0D7599	Lid assembly
S2	0D7730	Shaft assembly
S3	0D7731	Drain assembly
S4	0D7732	Motor assembly
S5	0D7733	Timer assembly
S6	0D7734	Command swith assembly
S7	0D7605	Reservoir assembly
S8	0D7735	Basket assembly

Exploded view - Structure

