

# Parts Catalog



Model RG30

## ELECTRIC ROLLER GRILL

MODELS:  
RG30 & RG50

1-16-2015

IMPORTANT!

TO EXPEDITE SHIPMENT OF PARTS, ALWAYS SPECIFY MODEL, REV,  
PART NUMBER, AND SERIAL NUMBER OF SLICER.

### GLOBE FOOD EQUIPMENT COMPANY

2215 East River Road

Dayton, Ohio 45439

#### Parts Department


Toll Free 1-800-745-6238 · Fax (937) 290-0585

E-Mail: [info@globefoodequip.com](mailto:info@globefoodequip.com)

Website: [www.globefoodequip.com](http://www.globefoodequip.com)

Not for resale

# RG30 & RG50 ROLLER GRILL COMPONENTS



# RG30 & RG50 PARTS LIST

## Roller Grill Part Numbers

ITEM	DESCRIPTION	RG30	RG50	QTY	ITEM	DESCRIPTION	RG30	RG50	QTY
1	SCREW	-	-	8	20	GRILL BODY	-	-	1
2	SIDE PANEL	-	-	2	21	MICA PLATE	U01991090026	-	1
3	CHAIN	U01191068005	-	1	22	POWER CORD & PLUG	U03021205012	-	1
4	MOTOR GEAR	U01021005059	-	1	23	STRAIN RELIEF	U02101155021	-	1
5	MOTOR	U03011200004	-	1	24	POWER SWITCH	U03041215027	-	1
6	CHAIN ADJUSTING ASSY	U06051470237	-	1	25	HEATING ELEMENT	U03061225040	U03061225042	11
7	SPRING PLATE	U01051025827	-	1	26	SCREW	-	-	15
8	SCREW	-	-	4	27	M4 NUT	-	-	13
9	FOOT	U02121165003	-	4	28	M4 WASHER	-	-	14
10	M5 WASHER	-	-	4	29	RIGHT BAFFLE	-	-	1
11	NUT	-	-	7	30	GUM COVER	U02101155052	-	22
12	E-CLIP RETAINING RING	U66991845009	-	2	31	QUADRIC SEALING	U02101155055	-	22
13	GEAR	U01021005035	-	3	32	ROLLER	U01091050029	U01091050028	11
14	SLEEVE	U01021005067	-	1		ROLLER, TEFLON	*U01091050055	*U01091050054	
15	BASE PLATE	-	-	1	33	LEFT BAFFLE (UPPER)	-	-	1
16	SCREW	-	-	5	34	RIGHT BAFFLE (LOWER)	-	-	1
17	INDICATOR LIGHT	U03091240005	-	2	35	ELEMENT FIXING PLATE	-	-	1
18	ENERGY SWITCH	U03041215007	-	2	36	SPRING	U01011000006	-	1
19	KNOB	U02101155013	-	2					
* Use after S/N 1413073962									

# WIRING DIAGRAM, RG30/RG50

