

Nacho Cheese Warmer

Part No. 38409

Instruction Manual

Model #2365, #2365LS and #2365EX



GOLD MEDAL[®]

FUNFOOD EQUIPMENT & SUPPLIES

Cincinnati, OH 45241-4807 USA

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw

CABINET ASSEMBLY PARTS LIST

Item No.	Model #2365 Part No.	Model #2365LS Part No.	Model #2365EX Part No.	Description
1	22038	22038	42369	Lead In Cord
2		38077		Socket, Lamp Holder
3	38227	38227	38227	Thermostat
4		38272		Light Baffle
5	38279	38279	38208	Tank Heat Element
6		38284		Sign Cover
7		38291		Lamp, 6 Watt White
8	38294	38294	38294	Insulation Wrap
9	38295	38295	38295	Insulation Bottom
10		38297		Retaining Angle
11	38303	38303	38303	Temperature Scale
12	38389	38389	38389	Knob, Heat Control
13	38417	38417	38417	Well Body, Welded Assembly
14	38419	38419	38419	Panel, Control
15	38420	38420	38420	Label, Fill to Line (not shown)
16		38421		Lighted Cabinet, Welded Assembly
17	38403		38403	Unlighted Cabinet, Welded Assembly
18		38423		Bottom Cover, Lighted
19	38418		38418	Bottom Cover, Unlighted
20	42532	42532	40328	Switch, Rocker
21	40353	40353	40353	Wire Nut, Black
22	42828	42828	42828	Sheet Metal Screw
23	47010	47010	47010	Label, Safe
24	47300	47300	47300	Tinnerman Fastener
25	74119	74119	74119	Warning, Disconnect Power
26	n/a	n/a	n/a	
27	76026	76026	76026	Strain Relief, Cord
28		82189		Label, Max. Lamp
29	87149	87149	87149	Label, Caution Disconnect
30		87223		Sleeving, Fiberglass
31	87247	87247	87247	Bumper, Headed Screw