

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)

Parts List – Cabinet Assembly

Item	Part No.	Description
1	47422	Light Bulb, Clear 7½ Watt (x2)
2	75040	Incandescent Lampholder (x2)
3	48018	Exhaust Blower
	47199	Blower Plug & Cord - Not Shown
4	38503	Nacho Cheese Sign (5582)
	38504	Nacho Cheese Sign (5583)
5	38448L	Hinge, Left Side (x2)
6	42532	Switch, DPST Rocker
7	47120	Knob
8	75267	Tee Bolt
9	38451	Heat Sink Plate (x2)
10	38533	Thermostat, 145°F
11	47236	Snap Bushing - Not Shown
12	47561	Magnetic Catch
13	22038	Lead-In Cord, 15 amp Plug
14	87194	Strain Relief
15	38534	Heat Element, Tubular 120V 400W
16	38473	Cover, Light Wires (x2) (5582)
	38474	Cover, Light Wires (x2) (5583)
17	38439	Bottom Plate, Cabinet (5582)
	38466	Bottom Plate, Cabinet (5583)
18	38447	Acrylic Panel (x2) (5582)
	38470	Acrylic Panel (x2) (5583)
19	47328	Glide (x4)
20	38440	Retainer, Display Sign (5582)
	38467	Retainer, Display Sign (5583)
21	38428	Door 1/8 Acrylic (5582)
	38455	Door 1/8 Acrylic (5583)
22	47264	Spacer, Thermostat Mount (x4)
23	79058	Thermostat, High Limit
24	38536	Clamp, Tubular Element
25	38429	Rack Assembly - Not Shown (5582)
	38456	Rack Assembly - Not Shown (5583)