



## **Ice Machine Parts List for AM0700 Series Dispenser Models**

**AM0711A**

**AM0721W**

**AM0712A**

**AM0722W**

**AM0713A**

**AM0723W**

**Manufactured August 1974 through October 1974**

## AM0700

### COMPRESSOR COMPARTMENT GROUP

	PART NO,
Compressor Assembly . . . . .	† 7620363
Components for Copeland Compressor	
Run Capacitor . . . . .	† 8503413
Start Capacitor . . . . .	† 8504223
Start Relay . . . . .	1502351
Overload Protector . . . . .	No Longer Available
Components for Bristol Compressor	
Run Capacitor . . . . .	† 8503413
Start Capacitor . . . . .	8503643
Start Relay . . . . .	No Longer Available
Low Side Service Valve 5/8" . . . . .	No Longer Available
Service Valve Seal . . . . .	1502781
Fan Motor . . . . .	No Longer Available
Fan Bracket . . . . .	No Longer Available
Fan Blade . . . . .	2400151
Air Condenser . . . . .	No Longer Available
Water Condenser . . . . .	No Longer Available
Water Regulator Valve . . . . .	1361171
Receiver . . . . .	† 1200221
Drier . . . . .	† 8930279
Brass Fusible Plug (Water condenser) . . . . .	1331011

### CONTROL GROUP

Expansion Valve . . . . .	No Longer Available
High Pressure Cut-out . . . . .	† 2355011
Solenoid Valve . . . . .	No Longer Available
60 Second Timer . . . . .	No Longer Available
15 Minute Timer . . . . .	2406071
Low Pressure Cut-in . . . . .	No Longer Available
Thermo-disc . . . . .	No Longer Available
Damper Door Switch . . . . .	† 2300799
Main Toggle Switch . . . . .	† 2300849
Push Button Switch (Ice and water) . . . . .	† 2301063
Push Button Switch Mounting Screw . . . . .	No Longer Available
Push Button Switch Mounting Lockwasher . . . . .	No Longer Available
Water Solenoid Valve . . . . .	2404051
Water Regulator . . . . .	No Longer Available
Terminal Board . . . . .	No Longer Available

### GEAR DRIVE GROUP

Gear Drive Motor . . . . .	No Longer Available
Gear Drive Assembly . . . . .	No Longer Available
Gear Drive Motor Bracket . . . . .	No Longer Available
Love-joy Coupling (With set screw & spider) . . . . .	No Longer Available
Keyway 3/16" Square x 1" Long . . . . .	No Longer Available
Auger 4" . . . . .	No Longer Available
Ice Chute Assembly 4" . . . . .	No Longer Available
Ice Chute Hood 4" . . . . .	No Longer Available
Upper Bearing Assembly . . . . .	No Longer Available
Lower Bearing Assembly . . . . .	No Longer Available

### EVAPORATOR ASSEMBLY GROUP

Left Hand Evaporator Assembly Dice . . . . .	No Longer Available
Right Hand Evaporator Assembly Dice . . . . .	No Longer Available
End Extrusion . . . . .	No Longer Available
Bottom Extrusion . . . . .	† 106991
Top Extrusion . . . . .	† 6068414

† Refer to Cross Reference Guide

## AM0700, CONTINUED

### ICE CHUTE GROUP

### PART NO.

Ice Chute Assembly . . . . .	No Longer Available
Ice Chute Hold Down Angle . . . . .	No Longer Available
Knurled Brass Screw . . . . .	No Longer Available
Damper Door Assembly . . . . .	No Longer Available
Harvest Rack . . . . .	No Longer Available
Bin Door Switch . . . . .	(See Control Group)

### WATER CIRCUIT GROUP

Right & Left Hand Water Sump Trough Assembly . . . . .	No Longer Available
Water Pump . . . . .	† 7626013
Float Valve Assembly . . . . .	† 8369049
Float Valve Bracket . . . . .	No Longer Available
Water Syphon Assembly (On sump overflow tube) . . . . .	No Longer Available
Water Distribution Tube Assembly . . . . .	No Longer Available
End Collar . . . . .	† 4408219
End Stopper . . . . .	† 4408209
Water Curtain . . . . .	127001
Water Supply Tube (Water pump to nylon tee 20" long) . . . . .	† 4420333
Nylon Insert Tee 1/2" . . . . .	No Longer Available
Water Supply Tube (From nylon tee to left & right hand nickel plated elbows 10" long) . . . . .	† 4420333
Water Supply Tube 2" Long (From elbow to water trough tube assembly) . . . . .	† 4420333
Nickel Plated Elbow (On water trough tube) . . . . .	No Longer Available

### CABINET GROUP

Top Front Panel . . . . .	109301
Bottom Front Panel . . . . .	No Longer Available
Rear Access Panel . . . . .	No Longer Available
Catch (For lower & top front panel) . . . . .	No Longer Available
Strike (Lower & top front panel) . . . . .	No Longer Available
Air Filter (Left hand side panel) . . . . .	No Longer Available
Stainless Steel Front Panel (Push button ice only) . . . . .	No Longer Available
Stainless Steel Front Panel (Push button ice & water) . . . . .	No Longer Available
Cyclac Top Cover (Under gear drive assembly) . . . . .	No Longer Available
Lock & Key Assembly (For lower and upper front panels) . . . . .	3060021
Master Key (For lock 3060021) . . . . .	No Longer Available
Cube Melting Tank . . . . .	No Longer Available
Stainless Steel Grill Assembly (Above cube melting tank) . . . . .	No Longer Available
Upper Front Panel Assembly . . . . .	109301
Lower Front Panel Assembly . . . . .	No Longer Available
Trim Extrusion (Dispenser) . . . . .	No Longer Available
Trim Extrusion Mounting Tape 30" Long . . . . .	† 9202129
Ice Decal (Above push button) . . . . .	No Longer Available
Water Decal (Above push button) . . . . .	No Longer Available
Decal (Place container here) . . . . .	No Longer Available
Hole Plug (Black) in Water Push Button Hole (When push button not used) . . . . .	No Longer Available

### CABINET GROUPS STAINLESS STEEL MODELS ONLY

Top Front Panel . . . . .	No Longer Available
Lower Front Panel . . . . .	No Longer Available

† Refer to Cross Reference Guide

**INTENTIONALLY LEFT BLANK**