

Star Manufacturing International Inc.


10 Sunnen Drive St. Louis, MO 63143

Phone: (314) 781-2777 FAX: (314) 781-3636 Installation and Operating Instructions

2M-Y4358 Rev. T 5-30-97

HOT DOG CHROME ROLLER GRILL MODELS 12, 25, 25X, 40, 45, 45X and 75

HOT DOG SILVERSTONE ROLLER GRILL MODELS 12S, 25S, 25SX, 40S, 45S, 45SX and 75S



Model 25









CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations. For equipment to be used by the general public, please contact the factory.

INSTALLATION:

This grill is equipped for the voltage shown on the nameplate. It will operate on alternating current only, however, the correct voltage must be applied.



CAUTION

DO NOT CONNECT TO DIRECT CURRENT (DC).

Connection Load:

Model 12, 12S 120V -610 Watts
Model 12, 12S 230CE- - 530 Watts
Model 25, 25S, 25SX, 25X- 1196 Watts
Model 40, 40S - 1636 Watts
Model 45, 45S, 45SX, 45X- 1696 Watts
Model 75, 75S -2656 Watts

The grill should be connected to a wall type receptacle, a direct line or separate circuit. A direct line or separate circuit is preferred. If the grill is connected on a line already overloaded, it will not operate properly. When installed, the unit should be level. Optional 4 inch adjustable legs are available.

GENERAL OPERATING PROCEDURES

For flexibility, all models of roller grills, excluding the I2, are divided into two independently controlled heat sections. The right control knob controls the rear cooking section and the left control knob controls the front cooking section. The I2 and I2S grills have only one heating section.

A signal light is provided next to each control knob to give a visual check if one or both sections are turned on.

Each section is controlled by means of a rotary switch with positions marked at OFF-HIGH-MEDIUM and LOW. On MEDIUM for all models except the 12 and 12S 230CE, it is normal for every other roller to be unheated. The 12 and 12S 230CE uses an infinite control which varies heat on all rollers.

Before cooking for the first time, wash all rollers with mild detergent solution and then wipe with a clean wet cloth.

Hot dogs should be kept refrigerated until ready for use. Always use hot dogs or sausages made for grilling.

NSF requires that perishable foods be kept at 140° F or above during serving periods. Do not keep hot dogs on the LOW setting for more than two hours. If held for more than two hours they must be transferred to HIGH or MEDIUM heated zone for cooking and serving.



CAUTION

USE ONLY PLASTIC OR COATED UTENSILS FOR HANDLING THE HOT DOGS. METAL WILL SCRATCH THE ROLLERS. WHEN COOKING, DO NOT TRANSFER HOT DOGS FROM HIGH TO LOW AS THEY MAY SHRINK. DO NOT OPERATE GRILL WITHOUT GREASE PAN IN PLACE.

Cooking time will vary depending on starting temperature and quality of the product. For best results follow the cooking systems shown below.

- Busy periods Set both controls on HIGH and fill to capacity.
- Medium periods Set control to HIGH to cook hot dogs. Reduce heat to MEDIUM as needed.
- 3. For all models except the 12 and 12S 230CE preheat hot dogs on LOW. Medium is used for preheating the 12 and 12S 230CE. Turn heat to HIGH for cooking as needed.

CLEANING:

Remove all hot dogs. Turn control to HIGH and allow rollers to get hot. Clean rollers with a clean wet cloth. Wipe from the outside ends towards the center of the rollers. Do not force grease into the roller end bearings.

Turn the grill off and remove the grease tray by pulling forward on the front edge. Clean the entire unit daily to insure long life and satisfactory performance as well as to maintain an attractive appearance. The exterior should be kept bright and attractive by using a mild detergent or non-abrasive cleaner.




CAUTION


DO NOT USE SHARP EDGES ON SILVERSTONE COATING - SCRAPES WILL VOID THE WARRANTY. NEVER USE STEEL WOOL OR ABRASIVE CLEANERS TO CLEAN ROLLERS AS THIS WILL DAMAGE THE FINISH AND POSSIBLY DAMAGE THE BEARINGS.


MAINTENANCE AND REPAIRS

Contact the factory, a service representative or a local service company for service or required maintenance.

RETAIN THIS MANUAL FOR FUTURE REFERENCE PART NO. 2M-Y4358 REV. S 4-24-97










MODEL 12/25/40/45/75

STAR MANUFACTURING INTERNATIONAL, INC.

SK1304 RI

REV. E

4-24-97





MODEL 25SX,25X,45SX,45X

STAR MANUFACTURING INTERNATIONAL, INC.

SK1392

REV. C

5-30-97

Grill-Max Roller Grills MODEL Series 12, 25, 40, 45 and 75

Key	Part	Number Per	
Number	Number	Unit	Description & Model Designation
1	2N-Y9947 2N-Y9541 2N-Y9946 2N-Y9543	7 10/14 10/14 10	ELEMENT 120V, 80W 12 ELEMENT 120V, 110W 25/40 ELEMENT 240V, 110W 25/40 ELEMENT 120V, 160W 45
2	2N-Y9945 A5-120102 PS-120145	10/16 7 7	ELEMENT 240V, 160W 45/75 ROLLER - CHROME PLATE (1.125" O.D.) 12 ROLLER - PLASTECH 88 (1.125" O.D.) 12S
	PS-250008 PS-250040 PS-450005 PS-450039	10/14 10/14 10/16 10/16	ROLLER - CHROME PLATE (1.125" O.D.) 25/25X/40 ROLLER - PLASTECH 88 (1.125" O.D.) 25S/25SX/40S ROLLER - CHROME PLATE (1.125" O.D.) 45/45X/75 ROLLER - PLASTECH 88 (1.125" O.D.) 45S/45SX/75S
3	2P-Z0467	14/20	TUBE GUIDE ASSEMBLY 12/25,45/28/32 40/75
4	2J-Y6689 2J-8006 2J-Y6690 2S-Y9225	1/2 1/2 2 1/2	PILOT LIGHT 120V (ROUND) 12/25, 40, 45 PILOT LIGHT 120V (SQUARE) 12/25, 40, 45 PILOT LIGHT 240V 75 PILOT LIGHT 230CE 12/25, 40, 45, 75
5	2R-9305 2R-Y9829 2R-Z0209	1/2 1/2 1/2 2	KNOB 12/25, 40, 45, 75 KNOB 12/25, 40, 45, 75 KNOB 12 230CE, 240VE/40SI 230CE KNOB 25, 40, 45, 75 230CE
6	NLA 2E-Y9252 2J-Y9226	1/2 2 1/2	SWITCH 12/25, 40, 45, 75120V/240V SWITCH 25, 40, 45, 75 230CE SWITCH, INFINITE CONTROL 12 230CE/40SI 230CE
7	2R-8229	2/4	KNOB SHIELD 12/25, 40, 45, 75
8	2U-Y6685 2U-Z0746	1 1	MTR CW 120V, LEFT CONTROL 25/25S, 40/40S, 45/45S MTR CW 240VLEFT CONTROL 25SX, 25X, 45SX, 45X75/75S MTR COM 420V, PICLYT CONTROL 42/42S, 25/25S, 40/40S, 45/45S
9	2U-Y6686 2U-Z0745	1	MTR CCW 120V, RIGHT CONTROL 12/12S, 25/25S, 40/40S, 45/45S MTR CCW 240V, RIGHT CONTROL 25SX, 25X, 45SX, 45X75/75S
10	2P-Y4183	1/2	MOTOR SPROCKET 12/25, 40, 45, 75
11	2P-Y5502 2P-Y4321 2P-Y6767 2P-Y4322 2P-Z0023 2P-Z0024	1 2 2 2 1 1	CHAIN - SHORT (110 Links) 12 CHAIN - SHORT (24 Links) 25, 45 CHAIN (116 Links) 40 CHAIN - LONG (128 Links) 75 CHAIN-SHORT (94 Links) 25SX, 25X, 45SX, 45X CHAIN-LONG 25SX, 25X, 45SX, 45X
12	PS-120160 PS-25RGRK PS-750004 A5-Z0670 A5-Z0671 A5-Z0672	1/2 2 2 1/2 2	CHAIN GUIDE ASSEMBLY (2 Stud Models Only) 12/40 CHAIN GUIDE ASSEMBLY (2 Stud Models Only) 25, 45 CHAIN GUIDE ASSEMBLY (2 Stud Models Only) 75 CHAIN GUIDE 12/40 (4 Stud Models Only) after 6/97 CHAIN GUIDE 25/45 (4 Stud Models Only) after 6/97 CHAIN GUIDE 75 (4 Stud Models Only) after 6/97
13	A5-Z0667 A5-Z0668 A5-Z0666 A5-Z0669	1 2 2 2	ELEMENT MOUNT 12 12 ELEMENT MOUNT 25/45 25, 45 ELEMENT MOUNT 40 40 ELEMENT MOUNT 75 75
14	A5-Y5482 A5-Y4238 A5-Y4308 2H-Y9229	1/2 2 2 2 4/8	TERMINAL BAR 7 12/40 TERMINAL BAR 5 25, 45 TERMINAL BAR 8 75 MICA WASHER (USED ON ELMT MNT & 12/25, 40, 45/12 TERM. BAR 7, 5 & 8) 75
	2I-Y9228	2/4	INSULATOR-CERAMIC (USED ON ELMT MNT 12/25, 40, 45/6 TERM. BAR 7, 5 & 8) 75



Grill-Max Roller Grills MODEL Series 12, 25, 40, 45 and 75

Key	Part	Number Per	
Number	Number	Unit	Description & Model Designation
17	A5-Y5484	1	DRIP TRAY 12
	A5-Y4248	1	DRIP TRAY 25
	A5-Y6769	1	DRIP TRAY 40
	A5-Y4249	1	DRIP TRAY 45
	A5-Y4250	1	DRIP TRAY 75
	A5-250032	1	DRIP TRAY ASSEMBLY 25SX, 25X
	A5-450030	1	DRIP TRAY ASSEMBLY 45SX, 45X
18	2I-Z0057	4/6	FOOT 12, 25, 45/40, 40S
19	Z1-115006	4	FOOT HOUSING (# 75000452 & BELOW) 75
19	2R-Y5092	4	4" FOOT (# 75000453 & UP) 75
20	2A-7612	4	FOOT (# 75000452 & BELOW) 75
21	2A-9347	4	FOOT EXTENSION (# 75000452 & BELOW) 75 STUD (# 75000452 & BELOW) 75
22 23	2C-9348 E4-403009	4	,
23	2E-Y9251	1	LEAD IN CORD 120V 12, 25 LEAD IN CORD 230CE 75 230CE
	C3-142023	1	LEAD IN CORD 230CE 75 230CE LEAD IN CORD 120V 40, 45
	2E-Y4343	1	LEAD IN CORD 230CE 40, 45 230CE
	A1-175122	1	LEAD IN CORD 230CE 12, 25, 40, 45 230CE LEAD IN CORD 240V 75
24	2K-7889	1	BUSHING - CORD 12, 25
47	2K-Y3240	1	BUSHING - CORD 12, 25 BUSHING - CORD 40, 45, 75
	2C-Y4003	3	CABLE CLAMP 12, 25 2M-Z0060
25	A5-Y9497	1/2	WIRE GUIDE 12/40 230CE
20	A5-Y9498	2	WIRE GUIDE 25, 45 230CE
	A5-Y9499	2	WIRE GUIDE 75 230CE
26	2E-Y9227	1	INLET 12, 25, 40, 45 230CE
	2E-Y9253	1	INLET 75 230CE
27	2C-Y9771	4	NUT, FOOT 75 230CE
28	2M-Z0022	1	LABEL-ROLLER GRILL ALL MODELS 12
	NLA	1	LABEL-ROLLER GRILL ALL MODELS 25,40
	2M-Z0060	1	LABEL-ROLLER GRILL ALL MODELS 45,75
29	A5-Z0673	1/2	TUBE-RETAINER (4 Stud Models Only) 12/40 after 6/97
	A5-Z0674	2	TUBE-RETAINER (4 Stud Models Only) 25/45 after 6/97
	A5-Z0675	2	TUBE-RETAINER (4 Stud Models Only) 75 after 6/97
NI	2I-H6579	4	MOTOR GROMMETS
NI	2A-Y4411	4	MOTOR MOUNTING PLATE
NI NI	A5-Y4239	1 1	MOTOR MOUNTING PLATE TONGS (NOT SHOWN)
INI	2P-Z0584	'	TONGS (NOT SHOWN)



STAR MANUFACTURING

10 Sunnen Drive, St. Louis, MO 63143 U.S.A. (800) 807-9054 (314) 781-2777 Parts & Service (800) 807-9054 www.star-mfg.com