


BL-4705-03



Fume Hood Valve Assembly

1	Screw, Handle	000922-45
2	Handle, Stem Valve	001149-20
3	Seat	000529-20
4	Asm, Spindle	005985-40
5	Locknut, Body Top	000959-40

