



TRCB Parts Manual





TO PLACE AN ORDER OR OBTAIN INFORMATION:

WEB SITE:

www.truemfg.com(Visit our Parts eStore at: http://estore.truemfg.com)
Parts Department e-mail address: parts@truemfg.com

SEND INQUIRIES TO:

TRUE MANUFACTURING COMPANY, INC. ATTN: PARTS DEPARTMENT St. Charles Industrial Center • P.O. Box 970 • O'Fallon, Missouri 63366 • U.S.A


CALL TOLL-FREE:

800-424-TRUE (Direct to Parts Department) or 800-325-6152 (U.S.A & Canada only)

OR CALL: 636-240-2400

FAX: 636-272-9471

Castors, Legs, Levelers & Accessories




<u>Accessories</u>



Castors, Plate Form





Castor Leg Mounting Plate



Castors (Stemmed) 5"



Legs Stemmed Standard




Leg, Seismec



<u>Compressors</u> 1/2 H.P. & Under. TRCB Cord, Power Accumulator/Capillary/S Condensing Unit TPP, uction Line TSSU, Outlet, TUC, TWT Compressor Cord, Power Motor Condenser Fan Accumulator Blade Cord, Power Condenser (Compressor) Fan Motor Overload Capacitor, Bracket, Start Condenser Relay Fan Motor Accumulator/ Capillary/ Suction Line Shroud, Compressor Condenser Pull Out Coil Compressor Block, Compressor Screen Coil, Condenser Capillary Tube Bolt, Compressor Drier, Compressor B Base, Compressor

Drawer Parts



Evaporator Parts TRC<u>B-50, 79, 119,</u> Cover, Cover, Evaporator, Evaporator Housing Cover-top - left side Coil, Evaporator Cover, Evaporator -Housing - right side Cover, Evaporator, Housing Blade Pan **Evaporator**, Evaporator Fan Motor Drain Elbow, Evaporator Drain Pan Motor, Evaporator Control, Fan Temperature Bracket, Evaporator Fan Plate, Thermometer Motor **Temperature** Control Tube, -Evaporator Pan, Drain Condensate Drain Bar, Condensate Drain Pan Kit, Evaporato Wicking Pad, Evaporator Wicking Heater Condensate Drain Pan Heater Drain Pan (One Piece)

Evaporator Parts
TRCB-52

