



## *CATALOG OF REPLACEMENT PARTS*

### *LG SERIES GAS FRYERS*

#### *MODELS*

*LG300  
LG400  
LG500*

*ML-136528  
ML-136622  
ML-136643*



For additional information on Vulcan-Hart or to locate an authorized parts and service provider in your area, visit our website at [www.vulcanhart.com](http://www.vulcanhart.com)




Fig. 1B

LG SERIES  
BURNER COMPONENTS

**BURNER COMPONENTS**

ILLUS. Fig. 1B	PART NO.	NAME OF PART	AMT.		
			LG300	LG400	LG500
1	00-499700-000G1	Tank Assembly .....	1		
	00-499701-000G1	Tank Assembly .....		1	
	00-499702-000G1	Tank Assembly .....			1
2	00-410681-00001	Burner .....	3	4	5
3	00-417714-00001	Hanger - Manifold Extension .....	1	1	1
4	00-408659-00005	Knob - Thermostat .....	1	1	1
5	00-411506-00013	Thermostat - Millivolt .....	1	1	1
6	00-419613	Bracket - Control .....	1	1	1
7	00-410840-00002	Thermostat - Hi-Limit (W/Stuff Box) .....	1	1	1
8	00-418209-00001	Manifold .....	1		
	00-418212-00001	Manifold .....		1	
	00-418318-00001	Manifold .....			1
9	00-010901-00039	Orifice - Spud (Nat. Gas) (Sea Level - 2000 Ft.) .....	AR	AR	AR
10	00-010901-00041	Orifice - Spud (Nat. Gas) (2000 - 3000 Ft.) .....	AR	AR	AR
11	00-010901-00042	Orifice - Spud (Nat. Gas) (3000 - 5000 Ft.) .....	AR	AR	AR
12	00-010901-00043	Orifice - Spud (Nat. Gas) (5000 - 7000 Ft.) .....	AR	AR	AR
13	00-010901-00044	Orifice - Spud (Nat. Gas) (7000 - 8000 Ft.) .....	AR	AR	AR
14	00-010901-00052	Orifice - Spud (L.P. Gas) (Sea Level - 2000 Ft.) .....	AR	AR	AR
15	00-010901-00053	Orifice - Spud (L.P. Gas) (3000 - 5000 Ft.) .....	AR	AR	AR
16	00-010901-00054	Orifice - Spud (L.P. Gas) (5000 - 8000 Ft.) .....	AR	AR	AR
17	00-410695-00001	Extension - Orifice .....	3	4	5
18	00-418208-00001	Hanger - Manifold .....	1		
	00-418211-00001	Hanger - Manifold .....		1	
	00-418317-00001	Hanger - Manifold .....			1
19	FP-085-74	Drain - Extension (1 <sup>1</sup> / <sub>4</sub> NPT Pipe) .....	1	1	1
20	00-414212-00006	Valve (1 <sup>1</sup> / <sub>4</sub> " Ball Drain) .....	1	1	1
21	00-410841-00022	Valve - Combination (Natural Gas) .....	1	1	1
22	00-410841-00023	Valve - Combination (L.P. Gas) .....	1	1	1
23	00-426505-00023	Flex Tube - Pilot .....	1	1	1
24	00-412212-00007	Pilot - (Nat. Gas) .....	1	1	1
25	00-412212-00002	Pilot - (L.P. Gas) .....	1	1	1
26	00-410839-00004	Thermopile, Millivolt .....	1	1	1
27	00-427952-00001	Bracket - Pilot Mounting .....	1	1	1
	00-417008-000G1	Heat Baffle for Burner .....	1	1	1
	00-497344-000G1	Wiring Harness .....	1	1	1




Fig. 2B

LG SERIES  
BODY UNIT

**BODY UNIT**

ILLUS. Fig. 2B	PART NO.	NAME OF PART	AMT.		
			LG300	LG400	LG500
1	00-419664-00002	Hanger - Basket .....	1	1	
	00-419664-00004	Hanger - Basket .....			1
2	00-499223-00001	Basket (Twin - Red Handle) .....	2	2	
	00-499223-00002	Basket (Twin - Red Handle) .....			2
3	00-427883-00001	Rack - Crumb .....	1		
	00-427883-00002	Rack - Crumb .....		1	
	00-427883-00003	Rack - Crumb .....			1
4	00-402558-00006	Clamp - Thermostat Bulb .....	2	2	2
5	00-417522-00001	Clip - Capillary .....	2	2	2
6	SD-036-03	Self-Tapping Screw 8-18 x 3/8" Hex Washer Hd., Type AB .....	4	4	4
7	SD-036-03	Self-Tapping Screw 8-18 x 3/8" Hex Washer Hd., Type AB .....	2	2	2
8	00-419778-00006	Body - L.H. Side .....	1	1	1
9	00-419656	Heat Shield .....	1	1	
	00-419656-00002	Heat Shield .....			1
10	00-419662-000G1	Front Panel Assembly .....	1	1	
	00-419662-000G2	Front Panel Assembly .....			1
11	00-417700-00002	Nameplate .....	1	1	1
12	00-421582-000G2	Door Panel Assembly (Stainless Steel) (Incls. Item 27) .....	1	1	
	00-421582-000G4	Door Panel Assembly (Stainless Steel) (Incls. Item 27) .....			1
13	00-419653	Handle .....	1	1	1
14	00-428023-000G1	Hinge - Assembly .....	1	1	1
15	SD-032-07	Self-Tapping Screw 10-24 x 1/2" Hex Washer Hd., Type TT .....	2	2	2
16	NS-044-09	Nut Assembly 10-24 Hex "KEPS" .....	2	2	2
17	SD-015-14	Self-Tapping Screw 1-4-20 x 1/2" Hex Washer Hd., Type TT .....	AR	AR	AR
18	00-413112-00012	Legs (6") (Stainless Steel) .....	4	4	4
19	00-421893-00001	Caster, 4" W/Brake .....	2	2	2
20	00-421893-00002	Caster, 4" .....	2	2	2
21	NS-044-14	Nut - 1/4-20 x 1/2 Hex Washer Hd., Type TT .....	AR	AR	AR
22	00-427886-00001	Body - Front Bottom .....	1	1	
23	00-497296-000G2	Magnet - Door .....	1	1	1
24	00-419778-00005	Body - R.H. Side .....	1	1	1
25	00-419788-00001	Shield - Front .....	1	1	
	00-419788-00002	Shield - Front .....			1
26	00-427884-00001	Body - Rear Bottom .....	1	1	
27	SD-032-07	Self-Tapping Screw 10-24 x 1/2" Hex Washer Hd., Type TT .....	4	4	4
28	00-419795-000G1	Insulation - Heat Shield .....	1	1	
	00-419795-000G2	Insulation - Heat Shield .....			1
29	00-416959-00006	Wrap - Flue .....	1	1	
	00-418336-00006	Wrap - Flue .....			1
	00-497428-00003	Body Bottom (21") .....			1




Fig. 3B

**LG SERIES  
ACCESSORIES**

ILLUS. Fig. 3B	PART NO.	NAME OF PART	AMT.		
			LG300	LG400	LG500
1	00-499223-00009	Basket - Single, Dual Handle .....	1	1	1
	00-499223-00010	Basket - Single, Dual Handle .....			1
2	00-421756-00001	Brush - Fryer Cleaning .....	1	1	1
3	00-410863-00002	Grease Strip .....	1	1	1
4	00-497211-00001	Vat Cover (SST) .....	1	1	
	00-497211-00002	Vat Cover (SST) .....			1

**RECOMMENDED SPARE PARTS LIST**

PART NO.	NAME OF PART	AMT.
00-410840-00002	High Limit .....	2
00-411506-00013	Thermostat-Millivolt .....	2
00-408659-00005	Thermostat Knob .....	2
00-410841-00022	Combination Valve (Nat. Gas) .....	1
00-410841-00023	Combination Valve (LP. Gas) .....	1
00-412212-00007	Pilot Assy. (Nat. Gas) .....	2
00-412212-00002	Pilot Assy. (LP. Gas) .....	2
00-410839-00004	Thermopile .....	2

NOTES