

PARTS MANUAL

1 🕜 😐 🥥

VULCAN

VHD SERIES HEAVY DUTY HOLDING & TRANSPORTATION CABINETS

MODELS:

VHD8	ML-138090
VHD15	ML-138091



For additional information on Vulcan-Hart or to locate an authorized parts and service provider in your area, visit our website at www.vulcanhart.com

VULCAN-HART DIVISION OF ITW FOOD EQUIPMENT GROUP, LLC www.vulcanhart.com

3600 NORTH POINT BLVD. BALTIMORE, MD 21222 F-41196 (08-10)

Vulcan ©2010 All Rights Reserved

Vulcan-Hart Food Holding and Transportation Cabinets are produced with quality workmanship and material. Proper installation, usage and maintenance will result in many years of satisfactory performance.

Before performing maintenance on the cabinet, thoroughly read the Service Manual and carefully follow all instructions in the order given. Refer to the Installation and Operation Manual for detailed operating instructions.

This manual is applicable only to models listed on the cover page.

To obtain Service and Parts information, contact Vulcan-Hart Service Department at the address listed on the front cover of this manual or refer to our website: <u>www.vulcanhart.com</u>.

Technical Service 1-800-814-2028

Service Parts 1-866-628-0485

When calling for Technical Service or Parts, have the model number and serial number available.

Notes:

(HEAVY DUTY)				
DESCRIPTION	WITTCO #	VULCAN #		
CASTER, 5" RIGID	CR-91-30-06R	851800	-786	
CASTER, 5" SWIVEL	CR-91-30-06S	851800	-787	
CORD, POWER 16/3 120V.	WP-052	851800	-6	
ELEMENT, 120V - 1000W	WP-105-1	851800	-151	
FAN, COOLING 120V	CR-91-80-90	851800	-647	
HANDLE, DOOR (RECESSED)	CR-91-27-49	851800	-739	
LIGHT, INDICATOR DUAL 240V	WP-106-2	851800	-22	
MAGNET, DOOR (BAR)	CR-91-27-59	851800	-742	
MOTOR, BLOWER	CR-91-48-57	851800	-761	
SLIDES, TRAY METRIC (EACH)	WP-291	851800	-310	
SWITCH, ROCKER	WP-191	851800	-272	
THERMOMETER, DIAL	WP-109	851800	-28	
THERMOSTAT	WP-110	851800	-30	
WHEEL, BLOWER	CR-91-48-58	851800	-665	

VHD8, VHD15 (HEAVY DUTY)