OPERATINGINSTRUCTIONS

MODEL NO. 965-B, -C, -D CHICKEN SLICER



Limited Warranty

This product is warranted to be free from defects in material and/or workmanship at the time of delivery only. A Proof of Purchase is required for all warranty claims.

Installation

- 1. After you have removed the Chicken Slicer from the carton, inspect the unit for signs of damage. If there is damage to the unit:
 - · Notify carrier within 24 hours after delivery.
 - Save carton and packing materials for inspection purposes.
 - Contact the Prince Castle Customer Sales Department at 1-630-462-8800 to arrange for a replacement to be sent.
- 2. Verify that all parts have been received.

Operation

- 1. Use only boneless chicken.
- Thoroughly cook chicken before slicing.
- 3. Place cooked chicken on slotted platform.
- 4. Lay cutting bars on top of chicken and press down firmly.
- 5. Use spatula to remove sliced chicken from frame and lift cutting bars to repeat process.
- 6. Use nylon brush (Prince Castle part no. 943-042) to remove any pieces of chicken left on cutting bars or slotted platform.



Note: Although the cutting bars are not sharp, please keep fingers and foreign objects away from cutting bars to prevent injury or damage to slicer.



Caution: Pieces of chicken left on cutting bars or slotted platform may cause tearing of chicken or damage to the slicer. Inspect the slicer after **each** use.

Cleaning


Regularly throughout the day and at closing, thoroughly clean and sanitize the Chicken Slicer.

- 1. Remove the hinge pin to release the cutting bars and slotted platform.
- 2. Spray the slicer parts with hot water to loosen chicken residue.
- 3. Brush the cutting bars and slotted platform with a nylon cleaning brush.
- 4. Wash the chicken slicer in cleaning solution, hot soapy water, or a dishwasher.
- 5. Rinse by spraying the slicer with hot water.
- 6. Soak/rinse the chicken slicer with sanitizer.
- 7. Allow to air dry.





Parts Identification



| Troubleshooting | |
|-----------------------|--|
| Difficulty in cutting | 1.Make sure cutting bars and slotted platform are cleared of any chicken pieces. |
| | Inspect cutting bars. Replace if bars are bent, twisted, or broken. |
| | Inspect slotted platform. Straighten or replace if bent. |

